

Introduction

Research

Goals

Results

Low Jitter

Spectro-  
scopy

Optical  
Guiding

Summary

# Creating low jitter plasma channel in a 3D–printed capillary, filled with gas Towards a Plasma Particle Accelerator

Ehud Behar

*Supervisors:*

Dr. Amir Capua and Prof. Arie Zigler

The Hebrew University of Jerusalem

# Table of Contents

## Introduction

Research

Goals

Results

Low Jitter

Spectro-  
scopy

Optical  
Guiding

Summary

## Introduction

Today's Particle Accelerators

Background to plasma

Preformed Plasma channel

Characterisation of the plasma

## Research Goals

## Results

Low Jitter

Spectroscopy measurement

Optical Guiding

## Summary

Introduction

Research

Goals

Results

Low Jitter

Spectro-  
scopy

Optical  
Guiding

Summary

The goal: design a low-jitter plasma channel for a meter-scale particle accelerator.

Applications:

- Experiments on the behaviour of nuclear matter
- Creating radiation sources for medical use

# Linear accelerators

Introduction

Research

Goals

Results

Low Jitter


Spectro-  
scopy

Optical  
Guiding

Summary

At present, all high energy accelerators run into limits.

- The accelerating electric fields must be less than 100 MV/m, to avoid material breakdown.
- Each GeV of energy requires  $\sim 100$  m of acceleration length.



# Laser Wake-Field Acceleration (LWFA)

A plasma-based charged particles accelerator

Introduction

Research

Goals

Results

Low Jitter


Spectro-  
scopy

Optical  
Guiding

Summary

Electrical breakdown is part of the design.

The power source is a laser beam or a charged particle beam.




Same as CERN, but in smaller scale.

# Limitations of LWFA

## Laser defocusing

Acceleration is achieved only when the laser beam is focused to  $\sim$  tens of  $\mu\text{m}$  in diameter.



Solution: Use a wave-guide.

# Waveguide

## Basic concept

Introduction

Research

Goals


Results

Low Jitter

Spectro-  
scopy

Optical  
Guiding

Summary



Light confined in core, cladding with a smaller refractive index.

# Construct a plasma waveguide

## Capillary Discharge

Introduction

Research

Goals

Results


Low Jitter

Spectro-  
scopy


Optical  
Guiding

Summary

Generate a plasma channel by means of electrical discharge.



Ablated capillary



Gas—filled capillary

Apply voltage ( $\sim$ kV) on the capillary ends to start a discharge.



# The Plasma state

Introduction

Research

Goals

Results

Low Jitter

Spectro-  
scopy

Optical  
Guiding

Summary

Ionised gas, electrically neutral.

Defined by  $N_e$  ( $\text{cm}^{-3}$ ) and  $T_e$  (eV).

Characteristic quantities:

Debye length 
$$\lambda_D = \sqrt{\frac{\epsilon_0 k_B T_e}{N_e e^2}}$$

Plasma Frequency 
$$\omega_p = \sqrt{\frac{N_e e^2}{m_e \epsilon_0}} \text{ rad/sec}$$

# Parabolic density profile

Introduction

Research

Goals

Results

Low Jitter

Spectro-  
scopy

Optical  
Guiding

Summary

Plasma dispersion relation:

$$\omega^2 = \omega_p^2 + c^2 k^2$$

The index of refraction  $\tilde{n}$  is

$$\tilde{n} = \frac{ck}{\omega} = \sqrt{1 - \frac{\omega_p^2}{\omega_L^2}} \approx 1 - \frac{\omega_p^2}{2\omega_L^2} = 1 - \frac{N_e}{2N_{\text{cr}}}$$

where

$$N_{\text{cr}} = \frac{\omega_L^2 \epsilon_0 m_e}{e^2}$$

is the critical plasma density.

# Parabolic density profile

Introduction

Research

Goals

Results

Low Jitter

Spectro-  
scopy



Optical  
Guiding

Summary

To achieve guiding, we need variation in  $\tilde{n}$ .

Ideally, the radial density profile (RDP) is parabolic:

$$N_e(r) = N_e(0) + \Delta N_e \left( \frac{r}{r_{ch}} \right)^2$$



# Characterisation of the plasma

## Hydrogen Spectrum

Introduction

Research

Goals

Results

Low Jitter



Spectro-  
scopy

Optical  
Guiding

Summary

Hot plasma emits light.

The emitted spectra can give information about  $N_e$  and  $T_e$ .



$$H_\alpha : \lambda = 656.28 \text{ nm}$$

# Stark Broadening

Introduction

Research

Goals

Results

Low Jitter

Spectro-  
scopy


Optical  
Guiding

Summary

Plasma is a charged medium.

Electric micro-fields perturb the atomic energy levels.

Averaging over different neighbours converts the Stark splitting to Stark broadening.



# Stark Broadening

Introduction

Research

Goals

Results


Low Jitter

Spectro-  
scopy

Optical  
Guiding

Summary

Line shape — a Lorentzian



Relation between  $N_e$  and  $\Delta\lambda_{1/2}$  is tabulated:

$$N_e = \left( \frac{\Delta\lambda_{1/2}}{\gamma(N_e, T_e)} \right)^{3/2}.$$

Weak dependence on temperature, in our experiment:

$$N_e [10^{18} \text{ cm}^{-3}] = \left( \frac{\Delta\lambda_{1/2} [\text{nm}]}{5.4} \right)^{3/2}.$$

# Table of Contents

Introduction

Research  
Goals

Results

Low Jitter

Spectro-  
scopy

Optical  
Guiding

Summary

## Introduction

Today's Particle Accelerators

Background to plasma

Preformed Plasma channel

Characterisation of the plasma

## Research Goals

### Results

Low Jitter

Spectroscopy measurement

Optical Guiding

### Summary

# Research Goals

Introduction

Research  
Goals

Results

Low Jitter

Spectro-  
scopy

Optical  
Guiding

Summary

1. Study of discharge evolution, low jitter of discharge ignition
2. Characterisation of the discharge, utilizing Stark broadening
3. Demonstration of optical guiding



# Experiment Scheme

Introduction

Research  
Goals


Results

Low Jitter

Spectro-  
scopy

Optical  
Guiding

Summary



Capillary inside a vacuum chamber, maintained at  $10^{-4}$  torr.

# Table of Contents

Introduction

Research

Goals

Results

Low Jitter

Spectro-  
scopy

Optical  
Guiding

Summary

## Introduction

Today's Particle Accelerators

Background to plasma

Preformed Plasma channel

Characterisation of the plasma

## Research Goals

## Results

Low Jitter

Spectroscopy measurement


Optical Guiding

## Summary

# Results

## Low Jitter

Plasma is generated, but not in a stable regime.



— Rogowsky coil reading

jitter  $\approx 80 \mu\text{s}$

# Use a laser pulse to ignite the plasma

Introduction

Research

Goals

Results


Low Jitter

Spectroscopy

Optical Guiding

Summary

The Nd:Yag laser pulse ionizes matter and detaches electrons.



# Experimental Results

## Low Jitter

Introduction

Research

Goals

Results



Low Jitter

Spectro-  
scopy

Optical  
Guiding

Summary

12 consecutive capillary discharges. Demonstrating low ignition jitter.



— Nd:Yag laser pulse  
— Rogowsky coil reading

$$\text{jitter} \approx 1 \pm 0.36 \text{ ns}$$

# Spectroscopy measurements

Introduction

Research

Goals

Results

Low Jitter

**Spectro-**  
**scopy**

Optical  
Guiding

Summary

- ▶ Plasma channel depth and density measurement
- ▶ Radial and longitudinal density profile
- ▶ Means: A spectrometer and a fast camera

# Radial density profile

Introduction

Research

Goals


Results

Low Jitter

Spectro-  
scopy

Optical  
Guiding

Summary



Imaging system —  $\times 5$  magnification.

iCCD camera 40 ns gate-on time.

# Data Analysis

Introduction

Research

Goals




Results

Low Jitter

**Spectro-**  
**scopy**

Optical  
Guiding


Summary



pixel size =  $26 \mu\text{m} \times 26 \mu\text{m}$



Fit a Lorentzian to each row of the data.



Stark Broadening on the order of 3 nm.


# Spectroscopy measurements

## Radial density profile

Density minimum on the axis of the capillary.

$$\Delta N_e \sim 4 \times 10^{17} \text{ cm}^{-3}$$


with  $r_{\text{ch}} \approx 50 \mu\text{m}$  and  $N_e(0) \approx 4 \times 10^{17} \text{ cm}^{-3}$ .



# Longitudinal density profile

## System setup

Verify longitudinal homogeneity of the plasma density.



The entire capillary length was imaged.


iCCD camera 1  $\mu$ s gate-on time.

# Longitudinal density profile

## Result

Mean plasma density  $\bar{N}_e$  of

$$\bar{N}_e \sim 3.3 \pm 0.8 \times 10^{17} \text{ cm}^{-3}.$$



# Optical guiding

## System setup

Introduction

Research

Goals

Results

Low Jitter


Spectro-  
scopy

Optical  
Guiding

Summary

System setup as before, but now adding an oscillator laser.

Pulses at a 84 MHz rate.



Beam aligned through the capillary, to a fast photo-diode.

# Optical Guiding

Introduction

Research

Goals

Results

Low Jitter

Spectro-  
scopy

Optical  
Guiding


Summary

Upon plasma discharge, we look for an increase in the detected amplitude — optical guiding.

$$\text{transmission ratio} = \frac{A_{t < 0}}{A_{\max}}$$

The explanation:

A plasma lens forms, the radiation is focused and trapped by the plasma.



# Optical guiding

## Results

Introduction

Research

Goals


Results

Low Jitter

Spectro-  
scopy

Optical  
Guiding

Summary



■ — Nd:Yag laser pulse

■ — Rogowsky coil reading

■ — detected oscillator signal

$$\frac{A_{t<0}}{A_{\max}} \approx 2.1$$

# Optical Guiding

Higher voltage difference

Introduction

Research

Goals


Results

Low Jitter

Spectro-  
scopy

Optical  
Guiding

Summary



■ — Nd:Yag laser pulse

■ — Rogowsky coil reading

■ — detected oscillator signal

$$\frac{A_{t<0}}{A_{\max}} \approx 8$$



# Duration of the plasma channel

Introduction

Research

Goals

Results


Low Jitter

Spectro-  
scopy

Optical  
Guiding

Summary

Correlation between applied voltage and the transmission ratio:



Duration of the plasma channel:

$$\Delta t_{\text{channel}} = 50 - 100 \text{ ns.}$$

# Table of Contents

Introduction

Research

Goals

Results

Low Jitter

Spectro-  
scopy

Optical  
Guiding

Summary

## Introduction

Today's Particle Accelerators

Background to plasma

Preformed Plasma channel

Characterisation of the plasma

## Research Goals

## Results

Low Jitter

Spectroscopy measurement

Optical Guiding

## Summary

# Summary

Introduction

Research

Goals

Results

Low Jitter

Spectro-  
scopy

Optical  
Guiding

Summary

Study of plasma channels generated in gas filled–capillaries.

- ▶ Low jitter of discharge ignition
- ▶ Verification of plasma conditions by spectroscopy means
- ▶ Demonstration of optical guiding

Future experiments —

Incorporating these capillaries in a LWFA scheme.